

Do you have one of these?



If so, continue to use it as normal.

If you have a Net2 desktop reader, proximity and magstripe USB but require some help on how to use it please contact us at: support@paxton.co.uk or call us on +44 (0)1273 811 011.

Would you like to purchase a Net2 desktop reader, proximity and magstripe USB?

Sales code: 350-910

Description: Net2 desktop reader, proximity and magstripe USB

NOTE: This unit requires Net2 v3.09 or later software, download this free here: <http://paxton.info/1438>. Please call Technical Support if you require advice.

Contact your installer for details or visit: <http://paxton.info/796>


I don't have a Net2 desktop reader, proximity and magstripe USB, what should I do?


Each Net2 magstripe card is encoded with a unique 8 digit number. New style packaging means that we will no longer be printing the 8 digit user number on cards.

To add new cards to a Net2 system we recommend using a Net2 desktop reader, proximity and magstripe USB for speed and accuracy.




However, you can use a CARDLOCK door reader if you want to add cards now.




- Select the doors menu in Net2. 
- Click on a convenient door.
- Select tab Reader 1 (if Inactive - select tab Reader 2).
- Select Desktop reader in the reader operating mode drop down box.

 Desktop reader

- Click yes and then apply - the door reader can now be used as a desktop reader to add tokens.



When you have finished adding tokens using the reader

- Select the doors menu in Net2. 
- Click on the door that you have been using as a desktop reader.
- Change the reader operating mode back to the original setting.
- Click Apply.

Please note that while a reader is being used as a Desktop reader, it will not function as a standard reader for opening doors.

For further information on how to add tokens, please go to:

<http://paxton.info/802>

Do you have one of these?



If so, continue to use it as normal.

If you have a Net2 desktop reader, proximity and magstripe USB but require some help on how to use it please contact us at: support@paxton.co.uk or call us on +44 (0)1273 811 011.

Would you like to purchase a Net2 desktop reader, proximity and magstripe USB?

Sales code: 350-910

Description: Net2 desktop reader, proximity and magstripe USB

NOTE: This unit requires Net2 v3.09 or later software, download this free here: <http://paxton.info/1438>. Please call Technical Support if you require advice.

Contact your installer for details or visit: <http://paxton.info/796>


I don't have a Net2 desktop reader, proximity and magstripe USB, what should I do?


Each Net2 magstripe card is encoded with a unique 8 digit number. New style packaging means that we will no longer be printing the 8 digit user number on cards.

To add new cards to a Net2 system we recommend using a Net2 desktop reader, proximity and magstripe USB for speed and accuracy.




However, you can use a CARDLOCK door reader if you want to add cards now.




- Select the doors menu in Net2. 
- Click on a convenient door.
- Select tab Reader 1 (if Inactive - select tab Reader 2).
- Select Desktop reader in the reader operating mode drop down box.

 Desktop reader

- Click yes and then apply - the door reader can now be used as a desktop reader to add tokens.



When you have finished adding tokens using the reader

- Select the doors menu in Net2. 
- Click on the door that you have been using as a desktop reader.
- Change the reader operating mode back to the original setting.
- Click Apply.

Please note that while a reader is being used as a Desktop reader, it will not function as a standard reader for opening doors.

For further information on how to add tokens, please go to:

<http://paxton.info/802>