

Connecting a Farpointe Prox data reader to Net2

Overview

The reader was tested with a Ranger wireless transmitter sending a 26bit Wiegand number.

Further information is available at: <http://www.farpointedata.com>

Paxton advise checking for the correct site code with the Wiegand filter to provide a higher level of security. To determine how this may be done see:


AN1010 - Configuring custom Wiegand formats < <http://paxton.info/990> >

AN1125 - Configuring Wiegand 26 bit with site code < <http://paxton.info/1753> >

To set up a Net2 Wiegand filter you will need to use the Net2 Server configuration utility. Once completed, set the reader 'Token data format' in Net2 to 'Wiegand Custom'.



Cable Pinout	ACU terminal
Red	+12V
-	Red LED
-	Amber LED
Brown	Green LED
Green	Wiegand D0
White	Wiegand D1
-	NOT USED
Black	0V



Ensure any unused wires are safely terminated.


To configure the LED setting, open the Net2 server configuration utility and on the 'General' tab, check the 'Display reader LED's in OEM style' box.

If the option is not available, please contact Technical support for further advice.

 +44 (0)1273 811011
 ✉ support@paxton.co.uk
 📞 paxton.support

 +49 (0) 251 2080 6900
 ✉ support@paxton-gmbh.de
 📞 paxton.gmbh.support


 +33 (0)157 329356
 ✉ support@paxtonaccess.fr
 📞 paxton.support


 +32 (0)78485147
 ✉ support@paxton-benelux.com
 📞 paxton.benelux.support


 +31 (0)76 3333 999
 ✉ support@paxton-benelux.com
 📞 paxton.benelux.support

 +27 (0)21 4276691
 ✉ support@paxtonaccess.co.za
 📞 paxton.support

 +1(800) 672-7298
 ✉ supportUS@paxton-access.com
 📞 usapaxton.support

 +11 5715088198
 ✉ soporte@paxton-access.com
 📞 paxton.soporte

 +1 (864) 751-3501
 ✉ soporte@paxton-access.com
 📞 paxton.soporte

 8000 3570 3783
 ✉ support@paxtonaccess.ae
 📞 paxton.support

 +44 (0)1273 811011
 ✉ support@paxton.co.uk
 📞 paxton.support