


Connecting a CDVI – DGLI (WLC) Proximity reader

Overview



Cable Pinout	ACU terminal
Red	+12V
Brown	Red LED
-	Amber LED
Green	Green LED
Yellow	Wiegand D0
Blue	Wiegand D1
-	NOT USED
Black	0V



Ensure any unused wires are safely terminated.

The token tested was 26 bit Wiegand format. The reader requires the ACU to control the LED's.


To configure the ACU LED setting, open the Net2 server configuration utility and on the 'General' tab, check the 'Display reader LED's in OEM style' box.

If the option is not available, please contact Technical support for further advice.

 +44 (0)1273 811011
 ✉ support@paxton.co.uk
 📞 paxton.support


 +49 (0) 251 2080 6900
 ✉ support@paxton-gmbh.de
 📞 paxton.gmbh.support


 +33 (0)157 329356
 ✉ support@paxtonaccess.fr
 📞 paxton.support

 +32 (0)78485147
 ✉ support@paxton-benelux.com
 📞 paxton.benelux.support


 +31 (0)76 3333 999
 ✉ support@paxton-benelux.com
 📞 paxton.benelux.support

 +27 (0)21 4276691
 ✉ support@paxtonaccess.co.za
 📞 paxton.support

 +1(800) 672-7298
 ✉ supportUS@paxton-access.com
 📞 usapaxton.support

 +11 5715088198
 ✉ soporte@paxton-access.com
 📞 paxton.soporte

 +1 (864) 751-3501
 ✉ soporte@paxton-access.com
 📞 paxton.soporte

 8000 3570 3783
 ✉ support@paxtonaccess.ae
 📞 paxton.support

 +44 (0)1273 811011
 ✉ support@paxton.co.uk
 📞 paxton.support