

# Connecting an HID Classic swipe reader to Net2

## Overview

The output from the reader can be either Wiegand or Clock & Data. The bit output from the reader is dependant on the card encoding used.

This should be confirmed with HID if it is not known to ensure that the correct parameters are used in the Net2 software. (Net2 server configuration utility)


The reader can be supplied with or without an LED.

To configure the LED setting, open the Net2 server configuration utility and on the 'General' tab, check the 'Display reader LED's in OEM style' box.

If the option is not available, please contact Technical support for further advice.



Cable Pinout	ACU terminal
Red	+12V
-	Red LED
-	Amber LED
Brown (if present)	Green LED
Green	Wiegand D0
White	Wiegand D1
-	NOT USED
Black & Screen	0V




Ensure any unused wires are safely terminated.

 +44 (0)1273 811011  
 support@paxton.co.uk  
 paxton.support

 +49 (0) 251 2080 6900  
 support@paxton-gmbh.de  
 paxton.gmbh.support


 +33 (0)157 329356  
 support@paxtonaccess.fr  
 paxton.support


 +32 (0)78485147  
 support@paxton-benelux.com  
 paxton.benelux.support


 +31 (0)76 3333 999  
 support@paxton-benelux.com  
 paxton.benelux.support

 +27 (0)21 4276691  
 support@paxtonaccess.co.za  
 paxton.support

 +1(800) 672-7298  
 supportUS@paxton-access.com  
 usapaxton.support

 +11 5715088198  
 soporte@paxton-access.com  
 paxton.soporte

 +1 (864) 751-3501  
 soporte@paxton-access.com  
 paxton.soporte

 8000 3570 3783  
 support@paxtonaccess.ae  
 paxton.support

 +44 (0)1273 811011  
 support@paxton.co.uk  
 paxton.support