

Connecting a HID MiniProx to Net2

Overview



The MiniProx is available as either pre-cabled or with terminal blocks. The output from the reader can be either Wiegand (base part number 5365) or Clock & Data (base part number 5368). This is factory or field configurable using configuration cards available from HID. Thebit output from the reader is dependent on the card encoding being used. This should be confirmed with HID if unknown, to ensure the correct settings are applied in the Net2 software.


As standard, the reader is set to control the LEDs. This must be changed to LED host control, using the configuration card HID06 LED and Beep card, available from HID.

Net2 does not require a media detect (mauve) connection from the reader.

To configure the LED setting, open the Net2 server configuration utility and on the 'General' tab, check the 'Display reader LED's in OEM style' box.

If the option is not available, please contact Technical support for further advice.

	Cable Pinout	ACU terminal
tb1-1	Red	+12V
tb2-7	Brown	Red LED
-	-	Amber LED
tb2-6	Orange	Green LED
tb1-3	Green	Wiegand D0
tb1-4	White	Wiegand D1
-	-	NOT USED
tb1-2	Black	0V
tb1-5	Screen	0V




Ensure any unused wires are safely terminated.

 +44 (0)1273 811011
 support@paxton.co.uk
 paxton.support


 +49 (0) 251 2080 6900
 support@paxton-gmbh.de
 paxton.gmbh.support


 +33 (0)157 329356
 support@paxtonaccess.fr
 paxton.support


 +32 (0)78485147
 support@paxton-benelux.com
 paxton.benelux.support


 +31 (0)76 3333 999
 support@paxton-benelux.com
 paxton.benelux.support

 +27 (0)21 4276691
 support@paxtonaccess.co.za
 paxton.support

 +1(800) 672-7298
 supportUS@paxton-access.com
 usapaxton.support

 +11 5715088198
 soporte@paxton-access.com
 paxton.soporte

 +1 (864) 751-3501
 soporte@paxton-access.com
 paxton.soporte

 8000 3570 3783
 support@paxtonaccess.ae
 paxton.support

 +44 (0)1273 811011
 support@paxton.co.uk
 paxton.support