

# Connecting a Identec Censu EC1 proximity reader to Net2

## Overview


The Censu EC1 has a fixed 26 bit Wiegand output, regardless of the encoding on the card. The token data format in the Net2 software should be left as the embedded 26 bit Wiegand format.

To configure the LED setting, open the Net2 server configuration utility and on the 'General' tab, check the 'Display reader LED's in OEM style' box.

If the option is not available, please contact Technical support for further advice.



Cable Pinout	ACU terminal
V+	+12V
-	Red LED
-	Amber LED
LED	Green LED
D0	Wiegand D0
D1	Wiegand D1
-	NOT USED
0V	0V




Ensure any unused wires are safely terminated.

 +44 (0)1273 811011  
 support@paxton.co.uk  
 paxton.support


 +49 (0) 251 2080 6900  
 support@paxton-gmbh.de  
 paxton.gmbh.support


 +33 (0)157 329356  
 support@paxtonaccess.fr  
 paxton.support


 +32 (0)78485147  
 support@paxton-benelux.com  
 paxton.benelux.support


 +31 (0)76 3333 999  
 support@paxton-benelux.com  
 paxton.benelux.support

 +27 (0)21 4276691  
 support@paxtonaccess.co.za  
 paxton.support

 +1(800) 672-7298  
 supportUS@paxton-access.com  
 usapaxton.support

 +11 5715088198  
 soporte@paxton-access.com  
 paxton.soporte

 +1 (864) 751-3501  
 soporte@paxton-access.com  
 paxton.soporte

 8000 3570 3783  
 support@paxtonaccess.ae  
 paxton.support

 +44 (0)1273 811011  
 support@paxton.co.uk  
 paxton.support