

Connecting a Farpointe P-500 ALPS Reader

Overview


The reader was tested with a Net2 Plus V6.00.7210 using Pyramid - UID Length 37 Bits.

The reader emits a constant Red LED, when a valid token is presented the reader will display a steady Green LED should the user be granted access. When a user is denied access the LED will flash RED and Green.



The wiring configuration between the Net2 Plus and the reader is as follows:

Cable Pinout	ACU terminal
Red	+12V
Orange	Red LED
-	Amber LED
Brown	Green LED
Green	Wiegand D0
White	Wiegand D1
-	NOT USED
Black	0V



Ensure any unused wires are safely terminated.

For further information please visit manufacturers site:
http://www.farpointedata.com/downloads/datasheets/P500_TDS.pdf



+44 (0)1273 811011
 support@paxton.co.uk
 paxton.support



+49 (0) 251 2080 6900
 support@paxton-gmbh.de
 paxton.gmbh.support



+33 (0)157 329356
 support@paxtonaccess.fr
 paxton.support



+32 (0)78485147
 support@paxton-benelux.com
 paxton.benelux.support



+31 (0)76 3333 999
 support@paxton-benelux.com
 paxton.benelux.support



+27 (0)21 4276691
 support@paxtonaccess.co.za
 paxton.support



+1(800) 672-7298
 supportUS@paxton-access.com
 usapaxton.support



+11 5715088198
 soporte@paxton-access.com
 paxton.soporte



+1 (864) 751-3501
 soporte@paxton-access.com
 paxton.soporte



8000 3570 3783
 support@paxtonaccess.ae
 paxton.support



+44 (0)1273 811011
 support@paxton.co.uk
 paxton.support